

DETRONS



Switch socket expert

JET
Series



DETRONS

At Detrons, we redefine excellence in electrical solutions by combining cutting-edge technology, superior craftsmanship, and elegant design. With a legacy of expertise in home automation and smart electrical systems, Detrons is committed to providing high-quality electrical sockets and outlets that meet the evolving needs of modern living.

Our electrical solutions are crafted with precision, durability, and efficiency in mind, ensuring seamless integration into residential, commercial, and industrial spaces. Whether it's a standard power outlet, smart socket, or USB-integrated design, every product in our lineup is built to enhance safety, optimize energy efficiency, and complement contemporary interiors.

At the core of Detrons' innovation is a commitment to quality, reliability, and user experience. Our range of sockets is designed to exceed international safety standards, offering secure and reliable power connectivity while incorporating smart features for the next generation of electrical installations.

With Detrons, you are not just choosing electrical sockets—you are choosing innovation, safety, and style. Explore our collection and experience the future of electrical solutions.



Contact Us



+971 2 584 6646



info@detrons.com



Regional Offices:

Dubai, UAE

Doha, Qatar


Riyadh, Saudi Arabia

Cairo, Egypt

www.detrons.com


	1 gang 2 way switch 250V/10A		Single 12A 3pin switched socket 250V/13A		computer socket
	2 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + 2 USB 250V/13A		TV + computer socket
	3 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + USB + Type C 250V/13A		Double computer socket
	4 gang 2 way switch 250V/10A		Single 3 pin MF switched socket 250V/13A		Satellite socket
	Doorbell switch 250V/10A		Single 3 pin MF switched socket + 2 USB 250V/13A		1 gang + fuse unit 250V/13A
	1 gang 2 way switch 250V/10A		Single 3 pin MF switched socket + USB + Type C 250V/13A		20A switch / 45A switch 250V/20A 250V/45A
	2 gang 2 way switch 250V/10A		Single 5 pin MF switched socket 250V/13A		Fan speed controller / Light dimmer
	3 gang 2 way switch 250V/10A		Single 15A switched socket 250V/15A		Double Light Dimmer
	4 gang 2 way switch 250V/10A		TV socket		European socket 250V/16A
	Doorbell switch 250V/10A		TEL socket		French socket 250V/16A

	1 gang + Dimmer switch		6 gang 2 way switch (146) 250V/10A
	Emergency switch		4 gang 2 way switch (146) 250V/10A
	Insert key for power		6 gang 2 way switch (146) 250V/10A
	Saver socket		Double 13A 3 pin switched socket 250V/13A
	Human body induction foot lamp		Double 13A 3 pin switched socket + 2 USB 250V/13A
	AC control		Double 13A 3 pin switched socket + USB + Type C 250V/13A
	Do not Disturb, please clean, Door bell		Double 3 pin MF switched socket 250V/13A
	Single HDMI		Double 3 pin MF switched socket + 2 USB 250V/13A
	Double HDMI		Double 3 pin MF switched socket + USB + Type C 250V/13A
	4 gang 2 way switch (146) 250V/10A		45A cooker unit 250V/13A+45A

	1 gang 2 way switch 250V/10A		Single 12A 3pin switched socket 250V/13A		computer socket
	2 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + 2 USB 250V/13A		TV + computer socket
	3 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + USB + Type C 250V/13A		Double computer socket
	4 gang 2 way switch 250V/10A		Single 3 pin MF switched socket 250V/13A		Satellite socket
	Doorbell switch 250V/10A		Single 3 pin MF switched socket + 2 USB 250V/13A		1 gang + fuse unit 250V/13A
	1 gang 2 way switch 250V/10A		Single 3 pin MF switched socket + USB + Type C 250V/13A		20A switch / 45A switch 250V/20A 250V/45A
	2 gang 2 way switch 250V/10A		Single 5 pin MF switched socket 250V/13A		Fan speed controller / Light dimmer
	3 gang 2 way switch 250V/10A		Single 15A switched socket 250V/15A		Double Light Dimmer
	4 gang 2 way switch 250V/10A		TV socket		European socket 250V/16A
	Doorbell switch 250V/10A		TEL socket		French socket 250V/16A

	1 gang + Dimmer switch		6 gang 2 way switch (146) 250V/10A
	Emergency switch		4 gang 2 way switch (146) 250V/10A
	Insert key for power		6 gang 2 way switch (146) 250V/10A
	Saver socket		Double 13A 3 pin switched socket 250V/13A
	Human body induction foot lamp		Double 13A 3 pin switched socket + 2 USB 250V/13A
	AC control		Double 13A 3 pin switched socket + USB + Type C 250V/13A
	Do not Disturb, please clean, Door bell		Double 3 pin MF switched socket 250V/13A
	Single HDMI		Double 3 pin MF switched socket + 2 USB 250V/13A
	Double HDMI		Double 3 pin MF switched socket + USB + Type C 250V/13A
	4 gang 2 way switch (146) 250V/10A		45A cooker unit 250V/13A+45A

	1 gang 2 way switch 250V/10A		Single 12A 3pin switched socket 250V/13A		computer socket
	2 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + 2 USB 250V/13A		TV + computer socket
	3 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + USB + Type C 250V/13A		Double computer socket
	4 gang 2 way switch 250V/10A		Single 3 pin MF switched socket 250V/13A		Satellite socket
	Doorbell switch 250V/10A		Single 3 pin MF switched socket + 2 USB 250V/13A		1 gang + fuse unit 250V/13A
	1 gang 2 way switch 250V/10A		Single 3 pin MF switched socket + USB + Type C 250V/13A		20A switch / 45A switch 250V/20A 250V/45A
	2 gang 2 way switch 250V/10A		Single 5 pin MF switched socket 250V/13A		Fan speed controller / Light dimmer
	3 gang 2 way switch 250V/10A		Single 15A switched socket 250V/15A		Double Light Dimmer
	4 gang 2 way switch 250V/10A		TV socket		European socket 250V/16A
	Doorbell switch 250V/10A		TEL socket		French socket 250V/16A

	1 gang + Dimmer switch		6 gang 2 way switch (146) 250V/10A
	Emergency switch		4 gang 2 way switch (146) 250V/10A
	Insert key for power		6 gang 2 way switch (146) 250V/10A
	Saver socket		Double 13A 3 pin switched socket 250V/13A
	Human body induction foot lamp		Double 13A 3 pin switched socket + 2 USB 250V/13A
	AC control		Double 13A 3 pin switched socket + USB + Type C 250V/13A
	Do not Disturb, please clean, Door bell		Double 3 pin MF switched socket 250V/13A
	Single HDMI		Double 3 pin MF switched socket + 2 USB 250V/13A
	Double HDMI		Double 3 pin MF switched socket + USB + Type C 250V/13A
	4 gang 2 way switch (146) 250V/10A		45A cooker unit 250V/13A+45A

	1 gang 2 way switch 250V/10A		Single 12A 3pin switched socket 250V/13A		computer socket
	2 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + 2 USB 250V/13A		TV + computer socket
	3 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + USB + Type C 250V/13A		Double computer socket
	4 gang 2 way switch 250V/10A		Single 3 pin MF switched socket 250V/13A		Satellite socket
	Doorbell switch 250V/10A		Single 3 pin MF switched socket + 2 USB 250V/13A		1 gang + fuse unit 250V/13A
	1 gang 2 way switch 250V/10A		Single 3 pin MF switched socket + USB + Type C 250V/13A		20A switch / 45A switch 250V/20A 250V/45A
	2 gang 2 way switch 250V/10A		Single 5 pin MF switched socket 250V/13A		Fan speed controller / Light dimmer
	3 gang 2 way switch 250V/10A		Single 15A switched socket 250V/15A		Double Light Dimmer
	4 gang 2 way switch 250V/10A		TV socket		European socket 250V/16A
	Doorbell switch 250V/10A		TEL socket		French socket 250V/16A

	1 gang + Dimmer switch		6 gang 2 way switch (146) 250V/10A
	Emergency switch		4 gang 2 way switch (146) 250V/10A
	Insert key for power		6 gang 2 way switch (146) 250V/10A
	Saver socket		Double 13A 3 pin switched socket 250V/13A
	Human body induction foot lamp		Double 13A 3 pin switched socket + 2 USB 250V/13A
	AC control		Double 13A 3 pin switched socket + USB + Type C 250V/13A
	Do not Disturb, please clean, Door bell		Double 3 pin MF switched socket 250V/13A
	Single HDMI		Double 3 pin MF switched socket + 2 USB 250V/13A
	Double HDMI		Double 3 pin MF switched socket + USB + Type C 250V/13A
	4 gang 2 way switch (146) 250V/10A		45A cooker unit 250V/13A+45A

	1 gang 2 way switch 250V/10A		Single 12A 3pin switched socket 250V/13A		computer socket
	2 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + 2 USB 250V/13A		TV + computer socket
	3 gang 2 way switch 250V/10A		Single 12A 3pin switched socket + USB + Type C 250V/13A		Double computer socket
	4 gang 2 way switch 250V/10A		Single 3 pin MF switched socket 250V/13A		Satellite socket
	Doorbell switch 250V/10A		Single 3 pin MF switched socket + 2 USB 250V/13A		1 gang + fuse unit 250V/13A
	1 gang 2 way switch 250V/10A		Single 3 pin MF switched socket + USB + Type C 250V/13A		20A switch / 45A switch 250V/20A 250V/45A
	2 gang 2 way switch 250V/10A		Single 5 pin MF switched socket 250V/13A		Fan speed controller / Light dimmer
	3 gang 2 way switch 250V/10A		Single 15A switched socket 250V/15A		Double Light Dimmer
	4 gang 2 way switch 250V/10A		TV socket		European socket 250V/16A
	Doorbell switch 250V/10A		TEL socket		French socket 250V/16A

	1 gang + Dimmer switch		6 gang 2 way switch (146) 250V/10A
	Emergency switch		4 gang 2 way switch (146) 250V/10A
	Insert key for power		6 gang 2 way switch (146) 250V/10A
	Saver socket		Double 13A 3 pin switched socket 250V/13A
	Human body induction foot lamp		Double 13A 3 pin switched socket + 2 USB 250V/13A
	AC control		Double 13A 3 pin switched socket + USB + Type C 250V/13A
	Do not Disturb, please clean, Door bell		Double 3 pin MF switched socket 250V/13A
	Single HDMI		Double 3 pin MF switched socket + 2 USB 250V/13A
	Double HDMI		Double 3 pin MF switched socket + USB + Type C 250V/13A
	4 gang 2 way switch (146) 250V/10A		45A cooker unit 250V/13A+45A